

# ***Line profile Edge detection***

*ME-CAE/2019*

Roland Pawliczek, PhD

---

Based on:


**NI Vision Assistant Tutorial**

**June 2011 372228M**

---


**Line profile → important part of Edge detection procedure**

For grayscale images, the step displays the **grayscale distribution along a line** of pixels in an image. For color images, the step displays the pixel distribution along a line for **each plane of the selected color model**. Using the **Line Tool**, **Broken Line Tool**, or **Freehand Line Tool** from the toolbar, click and drag to draw a line segment.




**Edge Detection: identifies boundaries that define an object.**

**Edge** - discontinuity in the intensity of the image color.




Edge Detection: identifies boundaries that define an object.



1 Search Lines	2 Edges
----------------	---------



Figure 6-5. Edge Detection with a Line Profile

Edge Detection: parameters.



1 Grayscale Profile	3 Hysteresis	5 Falling Edge Location
2 Threshold Value	4 Rising Edge Location	

Figure 6-6. Simple Edge Detection





### Vision Assistant: Machine Vision / Edge Detector function

Processing Functions: Machine Vision

Edge Detector: Detects edges in grayscale images.

**configuration of the edge search method**




Edge Detector Setup

Main | Edge Detector

Edge Detector: Simple Edge Tool



Look For: All Edges

Level Type:  Absolute Value

Line Profile: 

Edges Found: 2

OK | Cancel

### Vision Assistant: Machine Vision / Edge Detector function

The **Advanced Edge Tool** option allows for more accurate profile analysis.

Main | Edge Detector

Edge Detector: Advanced Edge Tool


Look For: First Edge

Edge Polarity: All Edges

Kernel Size: 3

Width: 3

Min Edge Strength: 24.610

Edge Strength Profile: 

Edges Found: 1

OK | Cancel

Edge Polarity: All Edges

Interpolation Type: Zero Order





Figure 8-8. Obtaining Subpixel Information Using Interpolation



Edge Strength Profile: 

Edges Found: 1

Vision Assistant: Machine Vision / Find Straight Edge function

Vision Assistant: Machine Vision / Clamp function


Automatically detect edges and perform distance measurement.



**Vision Assistant: Machine Vision / Caliper function**



Computes measurements—such as distances, areas, and angles— **based on results returned from other machine vision and image processing functions** (see help for Caliper function).

e.g. poiths form  
Edge Detector function

 Caliper: Displays the results of the measurement performed on the selected points.

Geometric Features Options:





**Vision Assistant: Machine Vision / Caliper function**

**Caliper Setup**

Caliper

Step Name  
Caliper 1

Geometric Feature:  
Distance 


Available Points

- 1- Edge Detector 1 - Edge 1
- 2- Edge Detector 1 - Edge 2

Select 2 points.

Measure

Reset    Select All    OK    Cancel



800x492 3X 7,7,6

Script:

Results ...	
Distance (1,2)	72,17 pixels

Vision Assistant: ROI – Region Of Interest



ROI is treated as "sub-picture" (subimage). It does not contain data from the image, but only stores information about the location in the area of the analyzed image.

ROI is used to determine the analysis area within a larger image → smaller region = faster analysis.

Vision Assistant: ROI – Region Of Interest

Table 6-1. NI Vision ROI Tools

Icon	Tool Name	Function
	Selection Tool	Select an ROI in the image and adjust the position of its control points and contours. Action: Click ROI or control points.
	Point	Select a pixel in the image. Action: Click the position of the pixel.
	Line	Draw a line in the image. Action: Click the initial position and click again at the final position.
	Rectangle	Draw a rectangle or square in the image. Action: Click one corner and drag to the opposite corner.
	Oval	Draw an oval or circle in the image. Action: Click the center position and drag to the required size.
	Polygon	Draw a polygon in the image. Action: Click to place a new vertex, and double-click to complete the ROI element.
	Freehand Region	Draw a freehand region in the image. Action: Click the initial position, drag to the required shape and release the mouse button to complete the shape.
	Annulus	Draw an annulus in the image. Action: Click the center position and drag to the required size. Adjust the inner and outer radii, and adjust the start and end angle.

